

# TECHNICAL DATA SHEET

**NAME:** MAGIC SPONGE

PART NUMBER(S): Q623

## PRODUCT DESCRIPTION:

Magic Sponge is an odorless non caustic cleaning sponge. Just dip it in water and you are ready to go. You can use Magic Sponge on virtually any surface and it will remove: scuff marks, lipstick, pen, pencil, dirt, grease, grime, finger prints, and more. It can be used on walls, wallpaper, doors, floorboards, tile, wood flooring, counter tops, dry-erase boards, copy machines, vinyl, glass, plastic trim, leather, hard furniture, outdoor furniture, shower doors, car wheels, stainless cookware, computer monitors and hardware, church pews, sneakers and more.

#### **Features and Benefits:**

- Reusable
- Contains no chemicals. Use only water
- Especially effective on permanent marker, crayon, ink, graffiti, lipstick, scuff marks, fingerprints, luggage marks, tea, soap scum, coffee, and wine stains
- · Shines chrome, brass, copper, and stainless steel

#### Use on:

Eliminates stubborn stains on walls, wallpaper, doors, floorboards, tile, wood flooring, countertops, work surfaces, lockers, signs, dry-erase boards, copy machines, vinyl, glass, plastic trim, leather, hard furniture, outdoor furniture, shower doors, car wheels, stainless cookware, computer monitors and hardware, church pews, sneakers and more.

### Directions for use:

- Wet the sponge completely and gently squeeze out excess water. Do not wring Scrub with the appropriate pressure until the stain is removed
- Follow with a dry cloth to remove damp areas and achieve optimal results
- Rinse the sponge with clean water to clear dirt residue. Squeeze dry and Store
- Dispose when white melamine cleaning surface is completely gone

**Note:** Test on a small area before applying to entire surface. Do not swallow or eat. Keep away from infants and children. Caution when applying to painted or finished surfaces as dulling may result.

Quantities:

30 UNITS/CASE





