

# **GREEN CHEM**

LABORATORIES



HIGH TEMPERATURE SEALANT ADHESIVE





330 PSI









RTV RED is ideal for use wherever a strong, permanently elastic weatherproof adhesive, sealant, or caulk is needed. Temperature range is from -60°F to 650°F. It is 100% silicone odorless and non-fuming. RTV RED is ompatible with engine oil, transmission fluid, and antifreeze. This product has excellent adhesion characteristics, high chemical resistance, and will not sag or shrink due to severe temperature extremes. Use for sealing cracks in machinery, heating and ventilating ductwork, plumbing fixtures, electrical connections, low-pressure water, and drainpipes. Forms in place gaskets. Bonds nameplates, machinery flanges, glass, signs and electrical insulation, etc. Ideal for caulking windows, doors, walls, ceiling cracks, and crevices.

### **DIRECTIONS FOR USE**

Surface should be clean and dry and free of oil, tar, dirt and dust for best adhesion. Hold can at 45° angle and apply a continuous bead of 1/16" to 1/8" to the mating surfaces. Starts to cure immediately, fully cures in 24 hours and reaches optimum strength in 7 days.

#### CAUTIONS

Contains Methyl Siloxane Linear/Cyclic (CAS#70131-67-8), Silica, Amorphous (CAS#7631-86-9), Mineral Seal Oil (CAS#64742-46-7), Methyltriacetoxysilane (CAS#4253-34-3), Ethyltriacetoxysilane (CAS#17689-77-9), Difluoroethane (CAS#75-37-6).

WARNING. Contains gas under pressure; may explode if heated. Causes serious eye irritation. Causes skin irritation.



## PRECAUTIONARY STATEMENT

If medical advice is needed, have product container or label at hand. Keep out of reach of children. Read label before use. Prevention: Wash hands thoroughly after handling. Wear protective gloves and eye protection. Response: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention. IF ON SKIN: Wash with plenty of soap and water. If skin irritation occurs: Get medical attention. Take off contaminated clothing and wash it before reuse. Storage: Protect from sunlight. Store in a well-ventilated place.

## READ SAFETY DATA SHEET BEFORE USING.



Leave a small bead of material which will form a sealing "plug" for reuse. To use, gently pull "plug" and begin to use material. If plug breaks leaving the dispensing tip sealed, use a paper clip or other wire object to remove and loosen the remainder of the cured material.

Green Chem Laboratories • www.GreenChemLabs.com • 1-800-964-3151